ICAN 30-300 DATASHEET

ICAN HALF MASK

Neoprene

ICAN HALF MASK 30-300 is a CC -marked half mask, tested and approved in accordance with European standard EN 140:1989, for the protection of the user's respiratory organs against harmful solid and liquid particles, fumes and gases.

ICAN HALF MASK 30-300 is a newly developed and state of the art half mask which provides safety and comfort in even the most exacting working environments.

Face blank:

30-300 is produced in soft neoprene rubber, which is kind to the skin. The anatomical design fits the shape of the face perfectly to provide maximum tightness and comfort.

Head harness:

30-300 is equipped with adjustable straps ("quick release") which ensure a rapid, perfect and comfortable fit. The two-piece head band ensures that the mask cannot slip and is thus held in the same position on the face during use

Filters:

Only ICAN-filters are tested and approved for use with 30-300. The filters have an ICANbayonet socket which enables quick and easy connection.

Always fit two new filters at the same time on 30-300. The bayonet socket's location on the filter means that, after fitting to the mask, the filter's centre of gravity is located close to the face, which provides good weight distribution and unhindered vision.

The following ICAN-filters are available for 30-300: P3 R, A2, A2-P3 R, A1B1E1-P3 R and A1B1E1K1-P3 R (Refer to technical data sheet for these filters). Please contact us if other filter types are needed

Exhalation valve:

Exhalation takes place through a very low resistance exhalation valve which is placed in a valve housing and is thus well-protected against contamination and impurities. The exhaled air is led directly out of the mask so that the air exchange is improved considerably since the amount of moist exhaled air remaining in the mask is kept to a minimum.



Front piece:

The straps on the 30-300 are fixed to a plastic front plate so that, when in use, the mask is pressed against the face with a uniformly distributed pressure, which provides the best and safest fit.

3 sizes:

30-300 is produced in 3 sizes: Small-Medium-Large. Whatever the user's facial shape and size, there are always a 30-300 which fits the user's face tightly and comfortably

Inhalation valve:

Inhalation takes place via two inhalation valves, whose natural rubber membranes offers only very low resistance.

HNICAL SPECIFICATIONS:		ICAN FILTERS - BAYONET SOCKET:		SPARE PARTS:	
		Class	Item no.	Item no.	Description
Face blank	Neoprene Rubber				
Straps (head)	Plasticband in two parts	P3 R	50-103	30-003	Strap set - complete
	and weavet elastic	A2	50-202	30-004	Valve set - complete
Straps (neck)	Weavet elastic	A2-P3 R	50-506		
Filters	ICAN-filters	A1B1E1-P3 R	50-653	Areas of use (examples):	
Filter connection	ICAN-bayonet socket	A1B1E1K1-P3 R	50-703		
Front piece	Plastic			★ The	chemical industry
Exhalation valve	Neoprene rubber membrane			★ The	medicine industry
Inhalation valve	Nature rubber membrane			★ The timber industry	
Sizes	Small-Medium-Large			★ The paint and varnish industry	
Weight	App. 170 Gram (Medium)			★ Ship	oyards
Colour	Black			★ Agri	culture
Approval	EN 140:1989 C€ 0200			★ Hor	iculture
		Please contact us if other fi	ter types are needed.	7	

Warning!

If the oxygen content of the air is less than 17% (by volume) oxygen, an air-supplied respirator must be used instead of filters.

If the polluted air's oxygen content is 17-21% (by volume), ICAN HALF MASK 30-300 can be used with ICAN particle filters, ICAN gas filters and ICAN combined filters with ICANbayonet socket.

If the air's gas content exceeds 0.1% (by volume), full face masks (ICAN FULL FACE 20-100, ICAN FULL FACE 20-300 B or ICAN FULL FACE 20-300 Y) should be used.

If the half mask is to be used in situations which require a particularly high degree of hygiene and comfort, or where there is a risk of adhesion of dyes, for example, it is recommended that the ICAN HALF MASK 30-500 non-allergic silicone half-mask is being used. This mask is also available in 3 sizes. Refer to technical data sheet for 30-500.

It is important that the instruction manual for half mask's is read carefully before use.



